

Hinge Mounting & Boring Locations

STENTO (2022-18)

Page 1 of 2
August 20, 2025
Reference

Cabinet	Type	Width x Height	Hinge Center Lines	Mounting Holes	Reference
6	S	21 15/16 x 26 15/16			
6	S	21 15/16 x 26 15/16			
8	P	17 9/32 x 31 5/16			
8	P	17 9/32 x 31 5/16			
8	P	17 9/32 x 31 5/16			
8	P	17 9/32 x 31 5/16			
17	S	12 1/16 x 20 7/16			
17	P	11 27/32 x 17 9/16			
17	P	11 27/32 x 17 9/16			
14	P	14 27/32 x 22 1/4			
14	P	14 27/32 x 22 1/4			
18	P	17 9/16 x 19 1/8	15 5/8, 3 1/2		Top
18	P	17 9/16 x 19 1/8	15 5/8, 3 1/2		Top
20	P	17 9/16 x 19 1/8	15 5/8, 3 1/2		Top
20	P	17 9/16 x 19 1/8	15 5/8, 3 1/2		Top
22	P	20 21/32 x 40 13/16			
22	P	20 21/32 x 40 13/16			
25	S	15 5/32 x 26 15/16			
27	P	19 x 51 3/16			
27	P	19 x 51 3/16			
27	S	19 3/32 x 51 3/16			
31	S	19 15/16 x 51 3/16			
31	P	18 9/16 x 51 3/16			
31	P	18 9/16 x 51 3/16			
2	P	17 23/32 x 22 7/16			
2	P	17 23/32 x 22 7/16			
2	P	17 23/32 x 22 7/16			

00 Hinge Mounting and Boring Locations HNGL01 NOTE

Hinge Mounting and Boring Locations

Cabinet	Type	Width x Height	Hinge Center Lines	Mounting Holes
2	P	17 23/32 x 22 7/16		